



Fold tape, adhesive sides together, to create a flap which will act as a switch.